



Ergonomic Setup



Height Adjustment

To adjust the monitor height, support the weight of the monitor with one hand. With the other hand squeeze the button marked "PUSH" then raise or lower using both hands.



Pan and Tilt Adjustment

can be adjusted in almost every direction and features:

- over 110° tilt adjustment
 over 180° pan adjustment
 portrait to landscape screen orientation.

