Assembly Instructions MODEL NO: Screw 8×16 **32PCS** Screw 5×20 2 STEP1 STEP2 1200W=1110 0 0 1500W=1410 A(T187) 1800W=1710 2PCS 4PCS STEP3 STEP4 0

IMPORTANT NOTE:

- Place all laminated parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials,including staples & packing straps before you start to assemble.
- Don't tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children

