## **Assembly Instructions** MODEL NO: Screw 8×16 16PCS Screw 5×20 2 20PCS STEP1 STEP2 1200W=1080 1500W=1380 1800W=1680 0 A(T187) 2PCS STEP3 STEP4

## **IMPORTANT NOTE:**

- Place all laminated parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials,including staples & packing straps before you start to assemble.
- Don't tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children

