Assembly Instructions Screw 8×16 STEP1 STEP2 1200W=1080 1500W=1380 1800W=1680 1200W=1080 1500W=1380 0 1800W=1680 Α 2PCS 1800W=1128 STEP3 STEP4

IMPORTANT NOTE:

- Place all laminated parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Don't tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children

