## Contents

1x Base Panel

1x Top Panel

2 x Side Panels

3x Centre Panels

4x Back Panels

12x Shelves

84x Cam Locks

84x Cam Fasteners

6x Heavy Duty Casters 24 x Self-Tapping Screws

24x Washers

## Unpack contents and lay out on floor

- 1. Identify each panel. Insert all cam locks and cam fasteners into place on each panel. Lay the 4 back panels on the floor with cam locks facing up.
- 2. Place one centre panel upright between two back panels (1).
- 3. Slide cam fasteners into corresponding holes on back panels. Lock into place. Attach 3 shelves to either side of the upright centre panel (2).
- 4. Attach the remaining 2 upright centre panels. Attach the remaining 6 shelves on either side (3). Attach the left and right side outer panels.
- 5. Attach top panel.
- 6. Attach bottom panel (identified by the pin holes on bottom of panel for castors). Turn upside down so bottom facing up.
- 7. Attach the 6 castors using the 24 self-tapping screws and washers.
- 8. Turn unit upright and insert your selection of colourful Tote Trays or natural Wicker Baskets (4).

