

ASSEMBLY INSTRUCTIONS





PLEASE NOTE*

Supplied timber top attaching screws are for use with top thicknesses of 25mm or greater. Do not use these screws if your top thickness is less tan 25mm