

ASSEMBLY INSTRUCTION


Remove all items from the carton . Verify all pieces before assembly.


PART LIST

KEY	QTY	DESCRIPTION	KEY	QTY	DESCRIPTION	KEY	QT Y	DESCRIPTION
1	5	Caster	8	2	Arm Bracket	14	2	Armrest
2	1	Base	9	8	Arm Bracket Screw	15		Backrest Tight Screw +Washers
3	11	Seat Post	10	6	Mechanism Screw	15	1	
4	1	Seat Post Cover	11	1	Backrest Post	16	1	Backrest Post Bellow
5	1	Mechanism	12	1	Backrest Screw	17	2	Backrest Post Bellow Screw
6	1	Seat	13	2	Arm Width Adjustment Knob + Washers	18	1	M5 Size Allen Wrench
	11	Backrest				19	1	M6 Size Allen Wrench














- A Pneumatic seat height adjustment
- B Seat angle adjustment: Seat angle adjusts independently with a single lever.
- C Backrest angle adjustment: Back angle adjusts independently with a single lever.
- D Sliding seat: It provides seat depth adjustment for different user leg lengths.

PREVENTIVE MAINTENANCE AND WARNING!

- USE THIS PRODUCT ONLY FOR SEATING ONE PERSON AT A TIME. DO NOT USE THIS CHAIR AS A STEP STOOL / LADDER. DO NOT SIT ON ANY PART OF THE CHAIR EXCEPT THE SEAT. DO NOT USE CHAIR ON UNEVEN FLOOR SURFACES. DO NOT USE CHAIR UNLESS ALL BOLTS, SCREWS AND KNOBS ARE TIGHT. AT LEAST EVERY SIX MONTHS, CHECK ALL BOLTS, SCREWS AND KNOBS TO BE SURE THEY ARE TIGHT.
- IF ANY PARTS ARE MISSING, BROKEN, DAMAGED OR WORN, STOP USE OF THE PRODUCT UNTIL REPAIRS ARE MADE USING FACTORY AUTHORIZED
- PARTS.
 DISPOSE OF PACKAGING PROPERLY. PLASTIC BAG IS NOT A TOY. DO NOT USE PLASTIC BAG AS HEAD COVERING IT MAY CAUSE SUFFOCATION. FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS