

Screen (all sizes) Assembly Instructions



SCREEN POLE (both heights) ASSEMBLY INSTRUCTIONS




Assembly Instructions

BRACKETS

Comes with:

4×16

Fixing Plate Set of 2




- N .→ Use 2 x provided screws to attach the plate to the screen Use 2 x provded screws to attach the top to the plate


MPORTANT NOTE:

- Place all laminated parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble. Don't tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children



Assembly Instructions





4×20

on a soft surface such as carpet or a rug. 0. *OPTIONAL STEP: Place table top upside down

Place leg upside down on top in desired location, and using a pencil mark the locations of the screw holes. Do this for both sides. Create pre-drill holes

is facing in. 1. Use the $4 \times \text{screws}$ provided to attach legs to top using an electric drill.
*NOTE: Make sure the side of the leg with 2 holes

